# TOA ROADLINE PAINT

SOLVENT BASED





o Vivid Colored with **Durable & Fast Dry** 

o Excellent Adhesion on both

Concrete & Asphalt surfaces

## **FEATURES**





















## TOA **SOLVENT BASED ROADLINE PAINT**





#### TOA Roadline Paint Reflective & Non-Reflective

Suitable for marking traffic on roads including curbs and sidewalks for concrete and asphalt surfaces

BLACK







718

708

719 Reflective Non-Reflective 709

 Reflective Non-Reflective 705

 Reflective 717 707 Non-Reflective

 Reflective Non-Reflective 713 Reflective 703 Non-Reflective

Remarks: The reflection has developed after the paint was applied, then partial of the paint film was scrubbed from the glass bead

by traffic and shown it's reflectivity that remain effective throughout the life of the paint film

#### Specification

Туре	Finish Film	Color	Application	Dilution (by volume)	Coverage (Sq.m. / Gallon / Coat)	Drying Time (hours)	
						(Surface Dry)	(Dry to recoat)
Acrylic Resin and Chlorinated Rubber	Matt Non-Reflective	Black / Red White / Yellow	Brush / Roller / Spray Gun	Mix with TOA Thinner No.81 (10-15% Approximately)	25 - 30	10-15 minutes	1 hour
	Matt Reflective		Brush / Roller				

### System

	Old Surface	New Surface			
Step 1 Surface Preparation	<ul> <li>Leave the surface to completely dry</li> <li>The surface to be used must be clean and free from dust, grease and stains. Oil stains, wax, salt stains and other contaminants</li> </ul>	<ul> <li>The surface to be used must be clean and free from dust, grease, oil stains, wax, salt stains, old paint and other contaminants.</li> <li>Chalk or deteriorated surfaces must be scrubbed clean with a nylon brush.</li> <li>Surfaces with moss and fungi should be removed with TOA113 Microkill</li> <li>Clean the surface with water and a suitable cleaner, then rinse with clean water again before leaving it to dry completely.</li> </ul>			
Step 2 : Primer	Note: In case of polished surface, it is recommended to paint the primer with TOA Penetrating Sealer at least 1 coat and let it almost dry for 3-4 hours to increase adhesion. Before painting with TOA Roadline Paint				
Step 3 : Topcoat	Topcoat : Apply at least 2 coats of TOA Road line Paint (Within each coat, let it dry at least 1 hour before applying the next coat).				

หมายเหตุ: สีที่เสดงพลหน้าจออยู่นี้ อาจมีการคลาดเคลื่อนจากสิจริง แนน่าก่อนสิ่งชื่อสามารถเร็คสิจริงจากเยิ้นงานตัวอย่าง ได้ที่ศูนย์ TOA ใกล้บ้านคุณ Remark: Colors on screens might differ from TOA Fandeck due to factors like lighting and device settings. To ensure accuracy, double-check with the shop that have TOA color sample boards or sample models around your location.





